





Tool Connections / Anschlüsse


Inhalt

<u>Overview by connections / Übersicht nach Anschlüssen</u>	<u>2</u>
<u>Overview by devices/ Übersicht nach Geräten</u>	<u>3</u>
<u>Connections / Anschluss ZIP-USB-MP</u>	<u>6</u>
<u>Connection / Anschluss ZTH EU / ZTH-GEN</u>	<u>10</u>
<u>Direct connection / Direktanschluss MFT-C</u>	<u>13</u>
<u>MP-Bus Tester (ZTH-GEN)</u>	<u>14</u>

Overview by connections
Übersicht nach Anschlüssen

Connection Anschluss	Matching Cable Passendes Kabel	MP level converters and devices MP-Pegelkonverter und Geräte	Page Seite
Service plug / Servicestecker 	ZK1-GEN 	 ZIP-USB-MP	6
		 ZTH EU / ZTH-GEN	10
Junction box / Anschlussdose 	ZK2-GEN 	 ZIP-USB-MP	6
		 ZTH EU / ZTH-GEN	10
		MP-Bus Tester	14
Weidmüller Plug / Weidmüller Stecker 	ZK4-GEN 	 ZIP-USB-MP	8
		 ZTH EU / ZTH-GEN	11
		MP-Bus Tester	14
RJ12 Socket / RJ12 Anschlussbuchse 	ZK6-GEN 	 ZIP-USB-MP	7
		 ZTH EU / ZTH-GEN	11
CR24 & NMV-D2M Socket / CR24 & NMV-D2M Anschlussbuchse 	ZK1-VAV 	 ZIP-USB-MP	9
		 ZTH EU / ZTH-GEN	12
Direct connection / Direktanschluss 	MFT-C 	 ZIP-USB-MP	13
		 ZTH EU / ZTH-GEN	13


Overview by devices /
Übersicht nach Geräte

 	ZK1-GEN 	Actuator / Antrieb 	10
	ZK2-GEN 	Junction box / Anschlussdose 	10
	ZK4-GEN 	VRP-M 	11
		BKN230-24MP 	11
	ZK6-GEN 	VRD3 	11
	ZK1-VAV 	NMV-D2-M 	12
		CR24 	12
	MFT-C 	Actuator / Antrieb 	13

Overview by devices /
Übersicht nach Geräte

Device Geräte	Cable Kabel	Connection Anschluss	Page Seite
	ZK1-GEN 	Actuator / Antrieb 	6
	ZK2-GEN 	Junction box / Anschlussdose 	6
		PC-Tool (MP-Master)	6
		MP-Bus Monitor	7
		MP-Bus Tester	14
	ZK6-GEN 	COU24A-MP 	7
		UK24MOD / UK24BAC 	8
	ZK4-GEN 	UK24LON / UK24EIB 	8
		VRP-M 	9
		BKN230-24MP 	9
	ZK1-VAV 	NMV-D2-M 	9
		CR24 	10
	MFT-C 	Actuator / NG-Antrieb 	13


Overview by devices /
Übersicht nach Geräten

Device Geräte	Cable Kabel	Connection Anschluss	Page Seite
MP-Bus Tester (ZTH-GEN) 	ZK2-GEN 	MP-Bus	14
	ZK4-GEN 	VRP-M 	14
		BKN230-24-MP 	14

Connections / Anschluss ZIP-USB-MP


ZK1-GEN to actuator /Service socket

ZK1-GEN an Antrieb / Servicebuchse




ZK2-GEN to junction box

ZK2-GEN an Anschlussdose



ZK2-GEN to MP bus (PC-Tool as MP-Master)


ZK2-GEN an MP-Bus (PC-Tool als MP-Master)



Connections / Anschluss ZIP-USB-MP


ZK2-GEN to MP bus (monitor mode)

ZK2-GEN an MP-Bus (Monitor-Betrieb)



ZK6-GEN to COU24-A-MP


ZK6-GEN an COU24-A-MP



Connections / Anschluss ZIP-USB-MP


ZK6-GEN to UK24MOD / UK24BAC

ZK6-GEN an UK24MOD / UK24BAC



ZK4-GEN to UK24LON / UK24EIB


ZK4-GEN to UK24LON / UK24EIB



Connections / Anschluss ZIP-USB-MP


ZK4-GEN to VRP-M

ZK4-GEN to VRP-M




ZK4-GEN to BKN230-24MP

ZK4-GEN to BKN230-24MP



via ZK1-VAV to NMV-D2M


via ZK1-VAV an NMV-D2M



Connection / Anschluss ZTH EU / ZTH-GEN


via ZK1-VAV to CR24

via ZK1-VAV an CR24



via ZK1-GEN to NG actuator


via ZK1-GEN an NG Antrieb



*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

via ZK2-GEN to junction box


via ZK2-GEN an Anschlussdose



Connection / Anschluss ZTH EU / ZTH-GEN

via ZK4-GEN to VRP-M


via ZK4-GEN an VRP-M



*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU


via ZK4-GEN to BKN230-24MP

via ZK4-GEN an BKN230-24MP



via ZK6-GEN to VRD3

via ZK6-GEN an VRD3




*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

Connection / Anschluss ZTH EU / ZTH-GEN

via ZK1-VAV to NMV-D2M


via ZK1-VAV an NMV-D2M



*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

via ZK1-VAV to CR24

via ZK1-VAV an CR24




*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

Direktanschluss / Direct connection MFT-C


Connection ZTH EU ZIP function

Anschluss ZTH EU ZIP Funktion




Connection ZIP-USB-MP

Anschluss ZIP-USB-MP




MP-Bus Tester (ZTH-GEN)

with ZK2-GEN
mit ZK2-GEN




*Only for ZTH-GEN available
Nur für ZTH-GEN verfügbar

with ZK4-GEN
mit ZK4-GEN



*Only for ZTH-GEN available
Nur für ZTH-GEN verfügbar



All-inclusive.



5-year
warranty



On site around
the globe



A complete
range of products
from one source



Tested quality



Short delivery
times



Comprehensive
support

Headquarters

BELIMO Holding AG
Brunnenbachstrasse 1
CH-8340 Hinwil
Tel. +41 43 843 61 11
Fax +41 43 843 62 68
info@belimo.ch
www.belimo.com

Subsidiaries, Representatives and Agencies

Albania
Algeria
Argentina
Australia
Austria
Bahrain
Belarus
Belgium
Bosnia
Brazil
Bulgaria

Cameroon
Canada
Central America
Chile
China
Croatia
Cyprus
Czech Republic
Denmark
Egypt
Estonia
Finland
France
Georgia
Germany
Greece
Great Britain
Hong Kong
Hungary
Iceland
India
Indonesia
Ireland
Israel
Italy

Japan
Jordan
Kazakhstan
Korea
Kuwait
Latvia
Lebanon
Libya
Lithuania
Luxembourg
Macedonia
Malaysia
Malta
Mexico
Moldova
Montenegro
Morocco
Netherlands
New Zealand
Norway
Oman
Pakistan
Philippines
Poland
Portugal

Qatar
Romania
Russia
Saudi Arabia
Serbia
Singapore
Slovakia
Slovenia
South Africa
Spain
Sri Lanka
Sweden
Switzerland
Taiwan
Thailand
Tunisia
Turkey
United Arab
Emirates
Ukraine
United States of
America
Vietnam